




Quick Start Guide

To quickly start watching satellite TV:

- 1 Apply power to the TracVision receiver.
- 2 Turn on your TV and select the satellite input (not VCR input).
- 3 Wait 30-60 seconds for the antenna to acquire the satellite TV signal. The TV will show the following messages:



- 4 If Message 1 does not appear after 30 seconds, press the remote control's SAT button.* Then press the remote's PWR button. The receiver beeps twice and its crescent-shaped Antenna Power light comes on.



- 5 If Message 2 does not appear after Message 1, ensure the antenna has a clear view of the satellite. The antenna requires an unobstructed view of the sky to receive satellite TV signals.


Once the antenna finds the satellite, and the receiver downloads the Program Guide, you can start watching TV!**

* If the SAT button doesn't illuminate red, replace the remote control's batteries.
 ** If your receiver is not activated, you will only be able to access the DIRECTV Preview Channel (100). Refer to the red Activation Card for details on activating the receiver for DIRECTV service.

Changing channels:

To change channels, select **A** **B** or **C**:

- A Press the CHANNEL(CH) button to tune to the next or previous channel.
- B Use the numeric keypad to enter the channel number.
- C Press the GUIDE button to bring up the **Program Guide**. Once you're in the Program Guide, use the joystick or CHANNEL(CH) button to scroll through the list, and press the SELECT button to tune to a channel.




Program Guide

Today	10:00 PM	10:30 PM	11:00 PM	11:30 PM
FX	Nip/Tuck		Rescue Me	
Travel Channel	Vegas Challenge		World Poker Tour	
Bravo	Showbiz Moms & Dads		Songwriters Hall of Fame	
CN	Yu-Gi-Oh!	Codename: Kids Next...	The New Scooby-Doo Movies	

Viewing a program description:

To view a description of the currently selected program, press the INFO button.



Troubleshooting:


Please see the reverse side of this guide.

Troubleshooting

TracVision system is not operating properly:

- 1 Stop your vessel.** Then turn on the TV and the TracVision system, as described on the reverse side of this guide.

Wait 1 minute, then check the status lights on the top of the receiver (the receiver connected directly to the antenna, if you have more than one). If all three lights are lit solid green, skip to **2**.



- A** VOLTAGE Light
- B** RECEIVER Light
- C** ANTENNA Light
- D** Main Power Switch
- E** Antenna Power Button

1a VOLTAGE light **A** is OFF:

- Ensure the main power switch (D) on the receiver's rear panel is turned ON. *The switch will illuminate green when flipped to the ON position.*
- Check the 12 VDC power to the receiver and check the in-line fuse.

VOLTAGE light **A** is ORANGE or Flashing RED:

- There are less than 10 volts input to the receiver. Try connecting the receiver to a dedicated circuit. *If your vessel is subject to power fluctuations, use a DC-DC converter to supply filtered power to the receiver.*

1b RECEIVER light **B** is ORANGE:


- The receiver is ON, but the antenna is OFF. Press the remote control's SAT button.* Then press its PWR button. The receiver beeps twice.
- If the antenna still doesn't come on, there might be a problem with the remote control.* Try pressing the Antenna Power button (E) on the receiver's front panel (crescent-shaped light should be lit green).

RECEIVER light **B** is Flashing ORANGE or RED:

- Contact your KVH dealer for assistance.

1c ANTENNA light **C** is Flashing GREEN:

- The antenna is on, but it hasn't yet found the satellite. Check for blockage. The antenna requires an unobstructed view of the sky to receive satellite TV. Common causes of blockage: buildings, trees, bridges, masts, and radars.
- Check the antenna dome for grime, which can affect reception. Heavy rain or moisture on the dome can also weaken satellite TV signals.



ANTENNA light **C** is RED:

- Check the coax cable that connects the receiver to the antenna. Be sure the connectors are undamaged and connected securely.

ANTENNA light **C** is Flashing ORANGE or Flashing RED:

- Contact your KVH dealer for assistance.

2 Program Guide starts to load, then stops in the middle of the process?

- Reset the LNB type on the receiver. Follow the steps in "Receiver Set to 'Unstacked LNB'" in Section 9 of the User's Guide.

If your satellite dish is ready for DIRECTV® service, please wait until your Advanced Program Guide™ is prepared.

Installation



3 TV picture is jumbled, frozen, or pixelated?

- Check for blockage as described in Step 1c.

4 TV displays a "Please call ext. 722" message and you can only watch the Preview Channel (100)?

- The receiver has lost its activation data. Call DIRECTV customer service at 1-800-DIRECTV.

5 The remote control has stopped working?

- Try the following: Press the SAT button, then try again. Replace the remote's two AAA batteries. Make sure the RF converter is plugged in, and try placing it in a different location. Also try aiming the remote directly at the RF converter. Or reprogram the remote (see Section 3-4 of the User's Guide).

See Section 9 of the User's Guide for more troubleshooting information.

* If the SAT button doesn't illuminate red, replace the remote control's batteries.